

INSTRUCTIONS FOR USE - ENGLISH

FAS_2°

METALLOGRAPHY CAMEO®DISK and TOUCHLAM® SYSTEMS

LAM PLAN patented self-adhesive rigid disc

- 1. Description of the LAM PLAN FAS® disc
- 2. Installation and use of the LAM PLAN FAS® disc
- **3.** Maintenance of the LAM PLAN FAS® disc



LAM PLAN S.A. - 7, rue des Jardins BP 15 - F 74240 GAILLARD Tél. : +33 (0)4 50 43 96 30 E-mail : mmsystem@lamplan.fr www.lamplan.com

1. Description of LAM PLAN FAS® disc

The LAM PLAN FAS® disc is a patented support adaptable on all polishing machines in metallography. It allows easy sticking and unsticking of the adhesive abrasive papers or adhesive pre-polishing discs and polishing cloths. It prevents from the tedious cleaning process of the plates, soiled by the glue residue, each time an adhesive disc is removed from it.

The LAM PLAN FAS® disc has a self-adhesive face so as to be stuck on your polishing machine support plate. Its thickness of only 1 mm keeps intact the plate's initial inherent flatness.

Eventual deformations of the LAM PLAN FAS® disc will automatically correct themselves after the sticking and few first uses.

Ø	Designation	References
200 mm	LAM PLAN FAS®2 DISC	05 FAS20 20
250 mm	LAM PLAN FAS®2 DISC	05 FAS20 40
300 mm	LAM PLAN FAS®2 DISC	05 FAS20 50
400 mm	LAM PLAN FAS®2 DISC	05 FAS20 80

3. Maintenance of the LAM PLAN FAS® disc

In order to resist to more than hundreds operations of sticking and unsticking discs, it is important to use carefully the LAM PLAN FAS® disc.

It should only be in contact with the adhesive face of the abrasive papers and of the pre-polishing discs and polishing cloths.

Avoid damaging your LAM PLAN FAS® disc, a deterioration of the surface would modify its attributes and it would have to be replaced prematurely.

For cleaning, use water-based detergent or isopropyl alcohol, do not use any other solvent.

WARRANTY

The batch number written on the identification label that is on all LAM PLAN FAS® discs must be kept. This label can be stuck on the back of your support plate.

The batch number of the LAM PLAN FAS® disc must be mentioned on all correspondences.

2. Installation and use of the LAM PLAN FAS® disc

The wearing of gloves is recommended to install the LAM PLAN FAS $^{\circ}$ disc.

Use the LAM PLAN FAS® on a flat, clean and dry plate (on request LAM PLAN can flatten your plate)

No mark of grease or solvent must remain. For an optimum cleaning, rinse the support plate with soap and water, then dry it under warm air.

Remove meticulously the protection film of the self-adhe-sive face.

Place the LAM PLAN FAS® disc on the support plate and apply a light pressure to make the contact. The grey face must be above. This pressure must be homogeneous and spread on the entire surface.

The adhesive is totally polymerised one hour after the installation.

WARNING ! THE STICKING IS UNCHANGEABLE

Mount the plate on the polishing machine and use it as a standard polishing support.

